



## How to find the License Code in EagleRIP Flexo?


1. Run RIPLicenseManagement from Windows Start, as following:




2. Click History on the License Management Utility



3. Click on the information line, as following:



4. Click Activate button as above, then you can find the License Code in Serial Number area, you can copy the code now.



end