

How to install SuperLine

1. Please make sure the dongle of SuperLine is plugged in.
2. Open **Senselock-dongleDriverV4.0.0.4** folder which in the installer folder, then double click **InstWiz3.exe** to install the driver of the dongle, just follow the guide and click **Next** button.
3. Run **Setup.exe** file which in **Setup** folder to install SuperLine, just follow the guide and click **Next** button.